



A-SeatSW (w/out dignity straps)

Size/ Trim Color	Recommended Weight range
A-SeatSW-S	31-75 Lb / 14-34 Kg
A-SeatSW-M	75-145 Lb / 34-66 Kg
A-SeatSW-L	145-220 Lb / 66-100 Kg
A-SeatSW-X	220-440 Lb / 100-200 Kg
A-SeatSW-XX	440-800 Lb / 200-363kg

Placing Seat Sling for Use



- If patient is in bed: elevate head of the bed and lean patient forward. Place sling behind patient with *label side down*.
- If patient is in wheelchair: lean patient forward and place sling behind patient with label side out.
- The leg wings should come along the sides of patient. Slide center of sling down to the coccyx area.



If head of bed cannot be elevated:

- Roll patient to one side and gently push the sling into the mattress and under the patient.
- Roll patient to other side and pull sling out and spread out under patient. Return patient to their back.





7







- Pull each leg wing underneath patient's legs just above the knee.
- Take left leg wing and pull through bottom loop of the right leg wing.
- Pull leg straps to straighten fabric under patient.

Updated 01/19 Page 1



A-SeatSW (w/out dignity straps)

Transferring patient with the seat sling



Attach straps to hanger bar:
FOR SEATED POSITION - Short loop for chest
straps and long loop for leg straps.
FOR SEMI-RECLINED TRANSFER - Long loop for
chest straps and short loop for leg straps.

2



After lifting, move patient by holding the sling or using one of the handles located on the back of the sling.



• For caregiver in front of patient:

Lower patient into chair by pushing gently on the leg wings.

For caregiver behind patient:

Use the handle to ensure patient's buttocks are in contact with the rear of the chair before lowering.

NOTE: While lowering patient, make sure their back is in constant contact with the chair.

Cleaning Instructions

- Wipe with approved hospital disinfectant between patients
- DO NOT soak in chlorine based solution
- DO NOT LAUNDER

Updated 01/19 Page 2